



APPENDIX H

Stormwater Pollution Prevention for Small Residential Construction Sites

Why do stormwater discharges from construction activities matter?

When it rains, stormwater washes over the loose soil on a construction site, along with various materials and products being stored outside. As stormwater flows over the site, it can pick up pollutants like sediment, debris, and chemicals from that loose soil and transport them to nearby storm sewer systems or directly into rivers, lakes, or coastal waters. EPA works with construction site operators to make sure they have the proper stormwater controls in place so that construction can proceed in a way that protects your community's clean water and the surrounding environment.

What Defines a Small Residential Construction Site?

A small residential construction site is a residential lot is a lot or grouping of lots being developed for residential purposes that will disturb less than 1 acre of land, but that is part of a larger residential project that will ultimately disturb greater than or equal to 1 acre.

What are ten steps to Stormwater Pollution Prevention on Small Residential Construction Sites?


The purpose of good housekeeping is to prevent daily construction activities from causing pollution. The following steps and detailed graphic on the next page are ten steps, some used in Kirkwood's Tree and Residential Infill programs, which are good practices to reduce stormwater pollution.

1. Protect any areas reserved for vegetation or infiltration and preserving existing trees
2. Stockpile you soil
3. Protect construction materials from run-on and runoff
4. Designate waste disposal areas
5. Install perimeter controls on downhill lot line
6. Install inlet controls
7. Install a concrete / stucco washout basin
8. Maintain a stabilized exit pad
9. Post your stormwater BMP site plan
10. Site stabilization



10 Steps to Stormwater Pollution Prevention on Small Residential Construction Sites

Stormwater management on small residential construction sites need not be complicated.



9 Post Your NOI and Keep an Up-to-Date Copy of Your SWPPP on Site
Post a sign or other notice of your permit coverage, including your NPDES tracking number and site contact information. Also, keep a copy of your complete and up-to-date SWPPP on site and easily accessible, including site maps showing where each BMP is or will be installed.

1 Protect Any Areas Reserved for Vegetation or Infiltration and Preserve Existing Trees
If you will be installing infiltration-based features such as rain gardens or bioswales, make sure these areas are designated as off limits to avoid compaction. Save time and money by preserving existing mature trees during construction. Preserving mature trees minimizes the amount of soil that needs to be stabilized once construction is complete, and minimizes the amount of runoff during and after construction activity.

2 Stockpile Your Soil
EPA's OGP requires operators to preserve native topsoil on site unless infeasible and protect all soil storage piles from run-on and runoff. For smaller stockpiles, covering the entire pile with a tarp may be sufficient.

3 Protect Construction Materials from Run-On and Runoff
At the end of every workday and during precipitation events, provide cover for materials that could leach pollutants.

4 Designate Waste Disposal Areas
Clearly identify separate waste disposal areas on site for hazardous waste, construction waste, and domestic waste by designating with signage, and protect from run-on and runoff.

5 Install Perimeter Controls on Downhill Lot Line
Install perimeter controls such as sediment filter logs or silt fences around the downhill boundaries of your site.

6 Install Inlet Controls
Sediment control logs, gravel barriers, and sand or rock bags are options for effective inlet controls. Make sure to remove accumulated sediment whenever it has reached half way up the control.

7 Install a Concrete/Stucco Washout Basin
Designate a leak-proof basin lined with plastic for washing out used concrete and stucco containers. Never wash excess stucco or concrete residue down a storm drain or into a stream!

8 Maintain a Stabilized Exit Pad
Minimize sediment track-out from vehicles exiting your site by maintaining an exit pad made of crushed rock spread over geotextile fabric. If sediment track-out occurs, remove deposited sediment by the end of the same work day.

10 Site Stabilization
Immediately stabilize exposed portions of the site whenever construction work will stop for 14 or more days, even if work is only temporarily stopped. Remember, final stabilization is required prior to terminating permit coverage.